






 30 min	 x2	 x2	 x1	 x1
---	---	---	--	---




Ax1



Bx1



Cx2
Ø8x38




Dx2
Ø7x4x38




Ex2
Ø7x3.5x18

1



⚠ WARNING	
<p>Children have died from furniture tipover.</p> <ul style="list-style-type: none"> • ALWAYS secure your television with an anchor device. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. 	

2





THAT'S ALL FOLKS

Share your style!

#KaveHome

